

FX 3000-IV: Exchange Proportional valve

- Open the instrument according to the document „3000-IV Open the instrument“
- Switch-off the instrument
- Disconnect the main cable and the pneumatic connection at the rear of the instrument
- Exchange the proportional valve, make sure the electrical and the pneumatic connections are connected correctly again

