

FX 3300-IV: Enabling license code

04/18, PN

Problem: License code is not enabled

Cause: License code has been deleted or option has been purchased

Solution:

1. Enter supervisor mode by selecting "Supervisor" on the display. Password is set to (no password required)
2. On the "Settings" screen select "License"
3. On the "License" screen select the required option and select "+"
4. Enter your license keys provide by TEXTTEST AG and select "save"

IF YOU DON'T KNOW YOUR LICENSE KEY, PLEASE CONTACT: info@texttest.ch