

FX 3000-IV: Exchange I/O-Board

- Open the instrument according to the document „3000-IV Open the instrument“
- Switch-off the instrument
- Disconnect the main cable at the rear of the instrument
- Exchange the board, make sure all cables are connected correctly again



